

How to connect the wireless Interconnectable Alarms to a group

1. Power On

To activate the alarm fit the base to the alarm, press and hold the Test/Hush button to make sure the alarm is working. *Please note the battery is sealed into the alarm.* (See figure 1)




Figure 1

Note - Group configuration must be completed within 50 seconds. After which time all units will return to the normal condition. We recommend laying out the alarms on a table during this process.

2. Enter Group Mode

Choose an alarm to be the 'master alarm'. To enter group mode press and release the Test/Hush button five times within five seconds. The sounder will emit a short beep and the red LED will flash every 0.5 seconds (see figure 2)




Figure 2

3. Add a unit to the group

To add a unit to the group, press and release the Test/Hush button on the second unit twice within 2 seconds. The sounder will emit a short beep to confirm the connection to the group (see figure 3)




Figure 3

4. End the group mode

When all units are added to the group, press and release the Test/Hush button on the first unit to end the the group configuration mode.

5. Removing a unit from the group

To remove a unit from the group press and release the Test/Hush button eight times within five seconds. The Sounder will emit two short beeps and the red LED will flash twice to confirm removal from the group (see figure 4)




Figure 4